



LEDLENSER HF8R


HF8R Core




HF8R Work




HF8R Signature




Magnetic Charge System




Transportation Lock




Boost




Boost Overheat Warning




Battery Indicator




Connecting System Adapter




Reset to default setting




Low Battery Warning




Comfort Pad




Helmet Adapter(HF8R Work)




Wall Holder (HF8R Work)




Universal Mounting Bracket (HF8R Signature)





Tilt Mechanism



Helmet Connecting System (HF8R Work)



Overhead Band




Ledlenser GmbH & Co. KG
Kronenstrasse 5-7 • 42699 Solingen • Germany
Phone +49 212/5948-0 Fax +49 212/5948-200
info@ledlenser.com



HF8R QUG_V1
2023.05.22
1J12A0505

LEDLENSER HF8R


HF8R Core/HF8R Work




Adaptive Light Beam




Direct to Red Mode (HF8R Core/HF8R Work)




Direct to RGB Mode (HF8R Signature)




HF8R Signature



Digital Advanced Focus System (Low Power/Mid Power/Power)



Bluetooth Controller (not included)



APP Mode

