




Type-C to Type-C







Battery Type: 21700
Chemical System Of Battery: Li-ion







Battery Replacement







Charge System









Charge temperature :0°C - 40°C
No charging below 0°C




High Temperature




Battery Indicator




Low Battery Warning





Pouch




Rotary Switch





Rotating



Touch
(Touch for Switching)



Release



Click
(Click for On to Off)


Mode 1















Mode 2













Mode 3









Mode 4







Ledlenser GmbH & Co. KG,
Kronenstr. 5-7, 42699 Solingen, Germany
Phone +49 212/5948-0 info@ledlenser.com

www.ledlenser.com